



# TECHLINE® CV QUICK INSTALL GUIDE

## Typical Netafim Techline CV Subsurface Layout Tips and Recommendations



Techline CV can be installed on-surface, under mulch, or buried evenly up to 6". Use guidelines on the back to select which Techline CV to use, and how to apply properly.

### Estimating How Much Techline CV to Use

Multiply the square footage of the area x 12, divide that number by the *minimum* recommended row of spacing from the General Guidelines Chart. (See back of sheet for more information.)

### Fittings


- Techline/Techline CV fittings are recommended. They are the fastest to install, most economical and do not require clamps at pressures less than 50 psi.
- 1/2" Poly insert fittings with clamps can be used.
- 700 Series compression fittings can also be used.

### Low Volume Control Zone

Pre-assembled valve, filter and pressure regulator is more convenient to use than separate valve, filter and pressure regulator.

### Two Versions:

- LVCZ10075-LF (0.25 - 4.4 GPM)
- LVCZ10075-HF (3.5 - 17.6 GPM)



**NETAFIM USA**  
5470 E. Home Ave. • Fresno, CA 93727  
888.638.2346 • 559.453.6800  
FAX 800.695.4753  
[www.netafimusa.com](http://www.netafimusa.com)

